



ELEVATION AT COLUMN LINE S7
(LOOKING WEST)

Step 10:
Move SBL to open bay.
Assemble rotation unit and lifting beam then rig it with strands.